

Installation Instructions

AE01K-C0561-001



DESICCANT REPLACEMENT For MR-052 Series

Description:

AE01K-C0561-001 1.25lb Color Indicating Silica Gel.

The desiccant used in the MR-052 series dehydrators is a distinct orange color. When exhausted it turns to a green color. Regeneration will restore the green color.

To replace the desiccant, unscrew the cap from the desiccant container. Remove the compression spring, the perforated disk and the felt filter. Remove the desiccant granules from the container.

To reassemble the unit, make sure the perforated disk is seated just above the bottom outlet fitting in the unit. Place one of the felt filters on top of this, and fill the unit with the desiccant refill. Place the second felt filter on top of the desiccant, and the second perforated disk on top of the filter. Place the spring on top of the perforated disk and screw the cap on tightly. The unit is now ready to be put back into service.

To regenerate the desiccant which has been removed from the unit, spread the desiccant evenly, one granule deep, on a tray. Heat for one hour at about 177°C or 350°F. The desiccant should then be cooled and stored in a tight container for future refilling of the acrylic desiccant container



**Customer Support Center
From North America**
Telephone: 1-800-255-1479
Fax (U.S.A.): 1-800-349-5444

International
Telephone: +1-779-435-6500
Fax Number: +1-779-435-8579

Web Access
Internet: www.commscope.com
Email: #mws@commscope.com

All designs, specifications and availability of products and services presented in this bulletin are subject to change without notice.

Bulletin AE01B-A0375-001 Rev F (05/11) © 2009 - 2011 CommScope, Inc. All rights reserved
CommScope, 3 Westbrook Corporate Center, Suite 900 Westchester, IL 60154 USA