

AE01K-D0817-002

Secondary Desiccant Canister



The MR050 dehydrator comes complete with a single desiccant canister. The unit is designed to house a secondary canister for extended desiccant drying capacity. Part number AE01K-D0817-002 is a complete secondary canister kit, which can easily be added to the system as follows.

The steps in the process are as follows. Isolate all transmission lines by turning the inline valve on the dehydrator to the "0" position. Access the desiccant canister(s) by removing the front panel. To add the second canister, pull one of the clear tubes from the barbed fitting on the original canister. Attach one clear tube from the new canister onto the barbed fitting on the original canister. Attach the clear tube that was removed to the barbed tee fitting on the tube that is now unattached. Repeat these steps for the second set of clear tubes. The second canister is now ready to be placed into the dehydrator, behind the original canister. The system is now ready to be returned to normal operation. Replace the front cover and turn the valve to the "1" position.



**Customer Support Center
From North America**
Telephone: 1-800-255-1479
Fax (U.S.A.): 1-800-349-5444

International
Telephone: +1-779-435-6500
Fax Number: +1-779-435-8579

Web Access
Internet: www.commscope.com
Email: #mws@commscope.com

All designs, specifications and availability of products and services presented in this bulletin are subject to change without notice.

Bulletin AE01B-A0438-002 Rev B (5/11) © 2009 - 2011 CommScope, Inc. All rights reserved

CommScope, 3 Westbrook Corporate Center, Suite 900 Westchester, IL 60154 USA